Miele

Operating Instructions



for the KM 451 Ceramic Cooktop

To prevent accidents and machine damage, read these instructions **before** installation or use.

USA CDN

M.-Nr. 05 361 900

Contents

Important Warning and Safety instructions 4

Help protect our environment 11
Disposal of packing materials 11
Disposal of an old appliance 11

Guide to the cooktop 12
Cooking zone controls and displays 14
Cooking zones 15

Before using for the first time 16
Cleaning and heating for the first time 16

Use 17
Touch controls 17
Turning on the cooktop 17
Turning on a cooking zone 18
Cooking without auto heat 18
Cooktop settings 19
Auto heat 20
Turning on an extended cooking zone 21
Turning off a cooking zone 21
To turn off the cooktop 22
Residual heat indicator 22
Safety lock 23
Safety cut-out feature 24
Overheating protection 26
Energy saving tips 27

Contents

Timer 28
To set the timer 28
Automatically turning off a cooking zone 29

Cleaning and care 30
Cleaning the ceramic surface 30

Frequently asked questions 31

Electrical connection 33

After sales service 34

IMPORTANT SAFETY INSTRUCTIONS

READ THE OPERATING INSTRUCTIONS CAREFULLY BEFORE USING THE COOKTOP

WARNING -

This appliance is intended for residential cooking only. The manufacturer cannot be held responsible for damage or injury caused by improper use or for uses other than those for which the appliance is intended.

When using your appliance, follow basic safety precautions including the following:

Installation

- Be certain your appliance is properly installed and grounded by a qualified technician in strict accordance with national and local safety regulations. The manufacturer cannot be held responsible for damage caused by incorrect installation or connection.

- To guarantee the electrical safety of this appliance, continuity must exist between the appliance and an effective grounding system. It is imperative that this basic safety requirement is met. If there is any doubt, have the electrical system of the house checked by a qualified electrician. The manufacturer cannot be held responsible for damages caused by the lack, or inadequacy of, an effective grounding system.

- Do not connect the appliance to the main electrical supply using an extension cord. Extension cords do not meet the safety requirements of this appliance.

- Before servicing, disconnect the power supply by either removing the fuse, unplugging the unit or manually "tripping" the circuit breaker.

Do not install the cooktop directly above a dishwasher, refrigerator or freezer. Heat radiated by the cooktop may damage them.

If the cooktop is installed above an oven, keep the cooktop's power cord from contacting the oven.

Because of the heat radiated it is not recommended to install the cooktop above a drawer. It should only be installed above a cabinet base unit with a dummy drawer front and an additional protective base between the appliance and the cabinet.

This equipment has not been designed for maritime use or for use in mobile installations such as aircraft or recreational vehicles. However, under certain circumstances it may be possible for an installation in these applications. Please contact the nearest Miele Dealer or the Miele Technical Service Department with specific requirements.

Use

Do not use the appliance until properly installed in the countertop.

This appliance is equipped with an overheating protection. See, "Overheating protection" for information.

Never use the appliance to warm or heat the room. Due to the high temperatures radiated objects left near the appliance could catch fire.

Protection from damage

- Do not drop anything on the ceramic surface of the cooktop. Although the ceramic glass is shock and scratch resistant, it is not shock or scratch proof.

- Do not use pots or pans with pronounced edges or ridges on the ceramic cooktop. These could scratch the cooktop permanently. Grains of salt and sand can also scratch.Make sure that the bases of any pots and pans are clean, free of any fat or oils and are dry.

- Do not allow either solid or liquid sugar, pieces of plastic or aluminium foil to fall on the cooking zones when they are hot. If these residues are allowed to cool on the ceramic surface pitting or even cracking could occur.

- Any spills should be removed as quickly as possible to prevent them from burning on and becoming difficult to remove.

- Do not use a steam cleaner to clean the appliance. Steam could penetrate electrical components and cause a short circuit.

- Never place hot pots or pans over the touch controls, as the underlying electronics may be damaged.

- In areas subject to infestation by cockroaches or other vermin, keep the appliance and its surroundings clean at all times. Any damage caused by pests will not be covered under warranty.

Injury prevention

Do not touch the cooktop or the area surrounding it during or immediately after use. The cooktop may be hot even though it is dark in color. Areas near it may become hot enough to cause burns. Do not touch, or let clothing or other flammable materials touch the cooktop or areas near it until they have cooled.
Wait until the residual heat indicators go out.

CAUTION: Do not store toys or items of interest to children in cabinets above or behind the appliance. Children climbing onto the cooktop to reach these items may be injured.

Children should not be left alone or unattended near the appliance when in use. They should never be allowed to sit or stand on any part of the appliance.

Protect your hands with insulated gloves or potholders when using the appliance. Use only dry, heat resistant potholders. Moist or damp potholders used on hot surfaces can result in steam burns. Do not let the potholder touch the hot heating element. Do not use towels or other bulky items near the appliance.

To prevent burns and breathing difficulty, allow the cooktop to cool before cleaning. Some cleaners may produce toxic fumes if applied to a hot surface.

Keep all pans out of reach of children. Danger of burns!

Pot and pan handles should be turned inward and not extend over the countertop to reduce the risk of burns, ignition of flammable materials, and spills.

Use the proper pan size.
Select cookware having flat bottoms large enough to cover the heating element. Using undersized cookware will expose a portion of the heating element to direct contact and may result in ignition of clothing or handles becoming hot. The proper size pot or pan will also improve effeciency.

Before using glass, glass/ceramic, ceramic, earthenware or other glazed cookware on the cooktop, verify that they can be used on a cooking surface.

Do not heat unopened food containers. Build-up pressure may cause the container to burst and result in injury.

At higher settings, be cautious of splattering grease or boiling over liquids, which may produce smoke.

IMPORTANT SAFETY INSTRUCTIONS

- Before removing pots and pans, be sure to turn off the burners.
- Do not store items on the appliance when not in use. Items could melt or catch fire from residual heat or if the cooktop is turned on inadvertently.
- Never cover the cooktop with a cloth. A fire could result.
- Never leave the cooktop unattended when cooking with oil or fat. Overheated fat could ignite. Always heat oil slowly, monitoring it as it heats.
- Do not use water on grease fires. Smother any fire or flame, or use a dry chemical or foam-type extinguisher.
- When frying food, make sure that the food is as dry as possible before placing it in the oil. Moisture can cause hot oil to splatter and boil over.
- Do not flambé under an exhaust hood. Flames could be drawn up into the hood by the suction or the grease filters may ignite.
- Do not let cooking grease or other flammable materials accumulate on the appliance.
- Wear proper clothing while cooking. Loose or hanging garments should never be worn while cooking.
- Flammable materials should not be stored on or near the appliance.
- If there is a drawer directly underneath the appliance without any wooden base in between, ensure that no aerosols, combustible liquids or other easily flammable materials are kept in it. If cutlery inserts are to be placed in the drawer, they must be made of heat-resistant material.

Appliance safety

In the event of any damage to the appliance, it must be turned off immediately and disconnected from the electricity supply by either removing the fuse or manually "tripping" the circuit breaker.
Contact the Miele Technical Service Department.
Do not use the appliance until it has been repaired.
Ensure power is not supplied to the appliance until repair work is completed.

Do not cook on a broken cooktop. Any breakages or cracks in the ceramic surface of the appliance are defects and must be treated as such.
If the cooktop should break, cleaning solutions and spills may penetrate the broken cooktop and create a risk of electric shock.
Do not use the appliance until it has been repaired.

Repairs should only be performed by qualified technicians to ensure safety. Repairs and other work by unqualified persons could be dangerous. Under no circumstances open the outer casing of the appliance.

While the appliance is under warranty repairs should only be performed by a Miele authorized service technician. Otherwise the warranty is void.

Further safety notes

When using a portable appliance near the cooktop, make sure that its power cord does not come into contact with the cooktop. The insulation of the power cord could be damaged. Danger of electric shock!

Always make sure food is sufficiently cooked or reheated. If in doubt, select a longer cooking or reheating time.

Only use cookware suitable for the range-top. Unsuitable cookware may break due to sudden temperature changes.

Do not use plastic or aluminium containers. They will melt at high temperatures. Fire hazard!

Do not heat empty pots or pans, they may be damaged.

Do not allow children to operate or play with, or near, the cooktop.

If a pet hops onto the cooktop, a touch control sensor could be activated and a burner turned on. Keep pets away from the cooktop at all times and activate the child safety lock.

Before discarding an old appliance, remove the power cord to prevent hazards.

SAVE THESE INSTRUCTIONS AND REVIEW THEM PERIODICALLY

Disposal of packing materials

The cardboard box and packing materials are biodegradable and recyclable. Please recycle.

Disposal of an old appliance

Old appliances contain materials that can be recycled. Please contact your local recycling authority about the possibility of recycling these materials.

Guide to the cooktop

Cooktop



①②④ Single zone

③ Extended zone

⑤ Variable zone

⑥ Control panel

Control panel



Touch controls for:

⑦ Cooking zone controls
(see section "Cooking zone controls and displays")

⑨ Child safety lock

⑩ Cooktop ON/OFF

⑪ Timer
(see "Cooking zone controls and displays")

Indicator for:

⑧ Child safety lock

Cooking zone controls and displays



Touch controls:

⑫ Cooktop ON/OFF

⑬ for selecting the power settings and turning on the outer circle of the variable zone or extended zone



Displays

⑭ Extended cooking zone on

⑮ 0 = Ready for use
1 - 12 = Power setting
-, = or ≡ = Residual heat
F = Fault (see ("Safety cut-out feature")

⑯ Light ring: the number of segments lit corresponds to the selected power setting
(exception: see "Cooking with Auto-heat").



Timer:

Kitchen timer or automatic shut off for rear left ◰ and front left ◱ zones

⑰ Time display

⑱ Touch controls for setting the timer

Cooking zones

Cooking zone	KM 451	
	ø in inches (cm)	Rating in watts
	5 3/4 (14.5)	1200
	8 1/4 (21)	2000
	6 3/4 (17) / 6 3/4 x 10 1/2 (17 x 26.5)	1400 / 2200
	5 3/4 (14.5)	1200
	4 3/4 (12) / 7 1/16 (18)	700 / 1700
		Total: 8300

All cooking zones have the auto heat and safety cut-out feature.

Cleaning and heating for the first time

Before using for the first time, clean the appliance with a damp cloth and then dry with a soft cloth.

Do not use liquid dish soap! Dish soap can leave a permanent blue sheen on the ceramic surface.

The metal components of the cooktop have a protective coating which may give off a slight odor the first time the appliance is heated.

The smell will dissipate after a short time and does not indicate a faulty connection or appliance defect.

Touch controls

This cooktop has electronic touch controls activated by a finger. There is a separate touch control for each cooking zone. A tone sounds to indicate that contact has been made with a touch control.

Keep the control area clean and do not rest things on it. The sensors could mistake an item or dirt for a finger tip contact, turning the cooktop on or off automatically (see, "Safety cut-out feature").
To prevent damage to the electronics never place hot pans on the control panel.

Turning on the cooktop

The cooktop must be turned on before any of the zones can be used.

Proceed as follows:

- Touch the ON / OFF touch control for the cooktop ⏻.

A horizontal bar in each of the zone displays appears and the timer displays *00*.

The cooktop is now turned on and the zones are ready for use. They will not heat up until a power setting has been chosen.

If no further entry is made the indicators will go out after 30 seconds, and the cooktop turns itself off as a safety measure. The residual heat indicators (see "Residual heat indicator") will stay on until the cooktop has cooled.

Turning on a cooking zone

Proceed as follows:

- When the cooktop is turned on, touch the control ⏻ of the desired cooking zone.

In the display of the cooking zone a *0* will appear.

- Select the desired setting between *1* and *12* by touching the **-** or **+** touch controls.
  Make sure to touch only one of the controls at a time or they will not respond.

When turning on the cooktop you can decide whether you want to cook with auto heat or not:

Turn on with + to:

Cook **without** auto heat

Turn on with - to:

Cook **with** auto heat

Cooking without auto heat

Proceed as follows:

- If *0* is showing in the display, keep the **+** touch control pressed until the desired power setting shows in the display, e.g. *4*:



The same number of segments ,⑯, will show in the light ring, i.e. if setting *4* is selected four segments will light up.

Cooktop settings

The range of settings is the same for all cooking zones:

Cooking process	Settings
Melting butter, chocolate etc. Dissolving gelatin	1 - 2
Thickening sauces containing egg yolk and butter Warming small quantities of food/liquid Warming sticky foods Cooking rice	1 - 3
Warming liquid and half-set foods Thickening sauces, e.g. Hollandaise Cooking rice pudding Preparing omelettes, lightly fried eggs Steaming fruit	3 - 5
Defrosting deep frozen food Steaming vegetables, fish Cooking dumplings, potatoes, soups Cooking broths	4 - 6
Boiling and continued cooking of large quantities of food	7
Gentle braising (without overheating the fat) of meat, fish, vegetables, fried eggs etc.	8 - 9
Frying pancakes etc.	9 - 11
Boiling large quantities of water	11 - 12

These setting recommendations are only intended as a guide. With deep pans, large quantities or without the lid on, a higher setting is needed. With smaller quantities select a lower setting.

Auto heat

When auto heat has been activated, the cooking zone turns on automatically at the highest setting and then changes to the continued cooking setting which you have previously selected. The "heat-up" time depends on which continued cooking setting has been chosen (see table).

Continued cooking setting	Heat-up time in minutes
1	0.5
2	2.0
3	2.5
4	3.0
5	4.0
6	6.0
7	9.0
8	2.0
9	2.0
10	2.5
11	2.5
12	-

How to activate auto heat:

- If *0* shows in the display, touch the **-** touch control until the continued cooking setting you want appears in the display e.g. *3*.

The **12 segments** show in the light ring ,⑯, during the auto heat time. When the heat-up time has finished **only the number of segments**, for the relevant **continued cooking setting** which has been chosen, show in the light ring.

Example:

during the auto heat time:



during the continued cooking time:



You can increase or decrease the continued cooking setting at any time during the auto heat time with the **+** or **-** touch controls. The heat-up time will adjust accordingly.

How to turn off auto heat before the heat-up time has finished:

- Set the display to *0*.
- Then select the setting you want to continue using by pressing the **+** touch control.

Turning on an extended cooking zone

The second circle of a variable cooking zone or the extended cooking zone can be turned on to extend the cooking area for cooking with larger pans.

Proceed as follows:

- Turn on the cooking zone and select a power setting.
- Press the **-** and **+** touch controls **simultaneously**.

When *0* appears in the cooking zone display the extended cooking zone can be turned on by pressing the **-** and **+** touch controls **simultaneously** and then selecting a power setting.

A short segment ,⑭, will appear in the top left of the ring to indicate that the extended cooking zone has been turned on.



To turn the extended cooking zone off, press the **-** and **+** touch controls **simultaneously**. The short segment ,⑭, will then go out.

Turning off a cooking zone

- Touch the ON / OFF control ⏻ of the cooking zone you want to turn off.

If the cooking zone is still hot, the residual heat indicator will remain lit until the zone has cooled (see "Residual heat indicator").

To turn off the cooktop

The cooktop can be turned off at any time.

- Touch the ON / OFF touch control ⏻ of the cooktop.

This turns off all cooking zones. The residual heat indicator will light up in the display of any cooking zone that is still hot.

Residual heat indicator

After the cooking zones or the cooktop have been turned off, the residual heat of the cooking zones which may still be hot are indicated by three stacked horizontal bars in the display:



The bars go out one after another as the cooking zones cool down. The last bar only goes out when the cooking zones are safe to touch.

If there is an interruption to the power supply the residual heat indicators will flash on and off.

Safety lock

Keep children away from the cooktop for their own safety. In addition, the cooktop has a child safety lock to prevent children turning on the cooking zones or changing the settings.

The child safety lock can be activated when the cooktop is turned off as well as when it is in use.

If the child safety lock is activated **when the cooktop is turned off** then the cooktop cannot be turned on.

If the child safety lock is activated **when the cooktop is in use** only the **following** are possible:

– The settings for the cooking zones and for the timer cannot be altered.

– The cooking zones, cooktop and timer can still be turned off but once turned off cannot be turned on again.

To activate the child safety lock:

■ Place a finger over the touch control for the child safety lock ⚷ until the indicator above it lights.

The indicator light will go out after a short while.

The light will come on again to show that the child safety lock has been activated, if:

– you touch the control for the child safety lock ⚷.

– you try to select a setting.

To de-activate the child safety lock:

Touch the control for the child safety lock ⚷ until the indicator light above it goes out.

Safety cut-out feature

The cooktop has a safety cut-out feature in case it is not turned off after use.

If one of the cooking zones is heated for an unusually long period of time (see table), and the power settings are not adjusted, the cooktop will turn itself off automatically and the appropriate residual heat indicator will appear.

- If you wish to use the cooking zones once again, turn the cooktop back on again in the usual way.

Power setting	Maximum length of operating time in hours
1	10
2	5
3	5
4	4
5	4
6	4
7	3
8	3
9	2
10	2
11	2
12	1

Safety cut-out if the touch controls are covered

The cooktop will turn off automatically if any of the touch controls are covered for more than 10 seconds, for example by finger contact, food boiling over, or by an object such as an oven mitt or towel.
At the same time as the cooktop turns itself off a tone will sound every 30 seconds (for a maximum of 10 minutes) and an *F* will flash in the display of the touch control which has been covered:

- Clean the control area or remove the object.

This will turn off the signal and the *F* will go out.

- Turn the cooktop back on again with the ON / OFF touch control ⏻. The cooking zones can now be used.

Overheating protection

Each burner is equipped with an internal temperature limiter. This automatically turns off the heating elements in the burner before the ceramic surface becomes too hot. Once the ceramic surface has cooled to a safe temperature, the heating will automatically turn back on again.

The overheating protection can be activated by:

– turning on a burner without putting a pan on it.

– heating an empty pan.

– an uneven pan not sitting evenly on the burner.

– the pan not conducting heat properly.

If the heating elements cycle on and off even when the highest setting is selected the overheating protection has been activated.

Energy saving tips

– Use pots and pans with flat or slightly concave bases for the most efficient cooking. The pan base should rest evenly on the ceramic surface when hot. Uneven bases can lengthen cooking times and cook food unevenly.



cold



hot

– To reduce heat loss, make sure the pot size and the size of the burner correspond.

too small



correct

– Cooking with a lid will also help prevent heat loss.

uncovered



covered

Cooking can be completed using the residual heat of the burners by turning the cooktop off 5 - 10 minutes before the food is finished.

Timer

The cooktop has two timers, one for the rear left cooking zone and one for the front left cooking zone. They can be used just as a kitchen timer, or for automatically turning one of these cooking zones off.

To set the timer

The timer can only be used when the **cooktop is turned on**, and the cooking zone belonging to the timer is turned off.

- With the **cooktop turned on** press the **-** or **+** touch control for the relevant timer until the desired time appears in the timer display e.g. 15 minutes.

The set time counts down in minutes in the time display. It can be changed at any time by pressing the **-** or **+** touch controls. The timer can be set from 1 to 99 minutes.

When the end of the set time has been reached *00* appears in the timer display, and at the same time a tone sounds for about 10 seconds. The *00* will go out after 30 seconds.

The timer can be turned off before the set time has elapsed by pressing the **-** and **+** touch controls **simultaneously**.

If the cooking zone belonging to the timer you are using is turned on, the timer will shut off. The time set goes out and *00* will appear in the display.

Automatically turning off a cooking zone

Only the rear left and front left cooking zones can be programmed to turn off automatically. This function will only work if a power setting has been selected.

Proceed as follows:

- Select a power setting for the relevant cooking zone.
- Press the **-** or **+** touch controls for the relevant timer until the desired time shows in the display, e.g. 15 minutes.



The time set counts down in minutes. The time left to run shows in the timer display. It can be changed at any time by pressing the **-** or **+** touch controls. The power setting for the cooking zone can also be changed at any time.

At the end of the selected time the cooking zone turns off automatically. The residual heat indicators will appear in the display for the cooking zone and a *00* in the timer display. At the same time a tone will sound for 10 seconds. The zeros will go out after 30 seconds.

Never use a steam cleaner to clean this appliance. Pressurized steam could cause permanent damage to the surface and to components.

Do not use any sharp pointed objects which could damage the seal between the ceramic surface and the surrounding frame and between the frame and the countertop.

Never use abrasive cleansers, scouring pads or strong cleaners e.g. oven sprays, stain or rust removers, as these could damage the surface of the appliance.

Do not use liquid dish soap to clean the cooktop. Dish soap can leave a permanent blue sheen on the ceramic surface.

Spills should be removed as quickly as possible to prevent them from burning on and becoming difficult to remove.

Turn off the cooktop immediately if any **sugar, plastic or aluminium foil** falls on to the cooking surface while in use. While the cooktop is hot, use a shielded scraper blade to clean off the surface. Take care not to burn yourself. Allow the cooktop to cool and clean with a ceramic cooktop cleaner.

Cleaning the ceramic surface

The ceramic surface should be cleaned regularly with a cleaner for ceramic surfaces. Follow the cleaner manufacturer's instructions.

Before cleaning allow the cooktop to cool. Wipe spills off using a damp cloth. Stubborn spills are best removed with a shielded scraper blade.

Apply the ceramic cleanser using a soft cloth to remove any limescale deposits or metallic water marks.

A cleaner with a special additive to prevent water marks and smears on the ceramic surface can be used.

After cleaning, wipe the ceramic surface with a damp cloth to remove any residue. Cleaner residues could damage the cooktop or create toxic fumes when heated. Finally, dry the cooktop with a clean soft cloth.

All repairs should be performed by a trained technician in strict accordance with national and local codes. Any repairs or maintenance performed by unqualified personnel could be dangerous and may void the warranty.

What if ...

the cooktop or cooking zones cannot be turned on?

Check whether:

– the child safety lock is activated. If necessary, turn it off (see "Child safety lock").

– the electrical circuit has blown a fuse or "tripped" the circuit breaker.

If none of the above is the case, then disconnect the appliance from the electricity supply for 1 minute by "tripping" the circuit breaker, or withdrawing the fuse.

Reconnect the appliance to the electricity supply and if the cooktop still does not heat up, contact a qualified electrician or the Miele Technical Service Department.

the cooktop turns off while it is in use and the residual heat indicator or a flashing *F* appears in the display for at least one of the cooking zones and at the same time a tone sounds?

One of the cooking zones has been on for too long, or one of the touch controls may have been covered (see, "Safety cut-out feature").

the heating cycles on and off at the highest setting on one of the cooking zones?

The Overheating protection is activated (see "Overheating protection").

the contents of the pan are not heating properly using Auto-heat?

The pan is a bad conductor of heat or too much food is in the pan.

Select a higher continued cooking setting or start by using the highest power setting and then turn to a lower setting.

the touch control sensors are over sensitive or do not react at all?

The sensitivity level of the sensor has been changed.

– Make sure that there is no direct light (from the sun or from an artificial source) hitting the cooktop and that the surrounding area is not too dark.

– Interrupt the power supply to the cooktop for 1 minute by "tripping" the circuit breaker, or withdrawing the fuse.

Reconnect the electricity supply. The electronic unit will have reset the sensitivity level of the touch control sensors.

If this does not solve the problem please call the Miele Technical Service Department.

All electrical work should be by a qualified electrician in accordance with local and national codes.
To reduce the risk of electric shock, disconnect the power supply by tripping the circuit breaker or removing the fuse to the unit before performing the installation or service.

■ **Note to the installer:**
Please leave these instructions with the consumer.

Power supply:

Please check the data plate for:

– 240 VAC, 60 Hz, 50 A,

– 208 VAC, 60 Hz, 50 A.

Make sure your electrical supply matches the data plate.

Important

The appliance is provided with 3 leads; L1 (black), L2 (red) and GND (green). They must be connected to a dedicated line through the use of an approved junction box.

For further information, see the wiring diagram provided with the appliance.

WARNING:
THIS APPLIANCE MUST BE GROUNDED!

After sales service

In the event of a fault which you cannot correct yourself please contact:

your Miele Dealer

or

the Miele Technical Service Department

USA 1-800-999-1360
techserv@mieleusa.com

CDN 1-800-565-6435
service@miele.ca

When contacting the Technical Service Department please quote the model and serial number of your appliance. These are shown on the data plate.

Please paste the copy of the unit's data plate here.

Miele, Inc.

National Headquarters
9 Independence Way
Princeton, NJ, 08540
Phone: 800-843-7231
609-419-9898
Fax: 609-419-1435
Technical Service: 800-999-1360
www.mieleusa.com

New England Showroom
555 Washington Street
Wellesley, MA, 02482
Phone: 781-431-2225
Fax: 781-431-0003

Southeast Regional Headquarters
7680 North Federal Highway
Boca Raton, FL, 33487
Phone: 561-995-8030
Fax: 561-995-8083

West Coast Regional Headquarters
680 Eighth Street
Suite 169A - Sobel Design Building
San Francisco, CA, 94103
Phone: 800-245-8215
415-241-6820
Fax: 415-241-6822

WEST COAST REGIONAL SERVICE 800-245-8215

Southern California Showroom
189 North Robertson Blvd.
Beverly Hills, CA, 90211
Phone: 310-855-9470
Fax: 310-358-0238

Mid West Regional Headquarters
3100 West Dundee Road
Suite 901
Northbrook, IL, 60062
Phone: 847-714-9433
Fax: 847-714-9434

Southwest Regional Office
1400 Turtle Creek Blvd.
Suite 177
Dallas, Texas, 75207
phone: 214-752-9000
fax: 214-752-6307

Miele Limited

Canadian Head Office
55G East Beaver Creek Road
Richmond Hill
Ontario L4B 1E5
Phone: 905-707-1171
Toll-Free: 1-800-565-6435
Fax: 905-707-0177
Internet: www.miele.ca
E-Mail: info@miele.ca
(general enquiries)
E-Mail: service@miele.ca
(technical service)

BC Regional Sales Office
3731 North Fraser Way
Unit 200
Burnaby
British Columbia V5J 5J2
Phone: 604-434-1300
Fax: 604-434-1309

Quebec Regional Sales Office
400 Laurier Avenue West
Suite 600
Montreal
Quebec H2V 2K7
Phone: 514-277-1818
Toll-Free: 1-877-636-4353
Fax: 514-277-1838

Alterations rights reserved / 002 - 0402

M.-Nr. 05 361 900

This paper consists of cellulose which has been bleached without the use of chlorine.